

How To Charge the Batteries

Note: Charge rate is set to 1 amp and the mode is set for LiPo batteries so it is simply plug and play. The CellPro will do the rest.

1. Attach charger to a 12 volt power source (Car battery or 12 volt power supply).
2. Attach the LiPo battery charging/balancing connectors to the adaptor cable. Position is marked with an arrow.
3. Place battery into LiPoSack.
4. When battery is charged, the charger will sound with a series of beeps.
5. Remove battery from the LiPoSack and unplug the battery from the adaptor.
6. Repeat for second battery if required.
7. Remove charger from the power source.
8. Do not charge all the batteries in the box. There are four batteries in the box, but two batteries are traveling spares. Only keep two batteries fully charged for the next pilot.

Rev: 5-8-11